FunTrek130 Pro/ FunTrek130

User Manual

Holux Technology Inc.

Copyright Declaration

HOLUX is trademarks of HOLUX Technology, Inc.

All other trademarks belong to registered companies.

- The contents of this manual will be modified without further notice.
- Without the written consent of HOLUX Technology, Inc, this manual may not be translated or copied. Copyright HOLUX Technology, Inc. All rights reserved.

Software Copyright

FunTrek130 software is China and international copyright law protection. Copyright HOLUX Technology, Inc. All rights reserved. Other products mentioned herein and company names are trademarks of their respective owners.

Notice:

This manual applies to FunTrek130 Pro/ FunTrek130/ FunTrek130 series models. However, the descriptions on ANT+ heart rate/ ANT+ bike cadence and ANT+ bike speed sensor features are only applicable only on FunTrek130 Pro/ FunTrek130; FunTrek130 does not support these features.

Product Caution

About operation environment

- The operating temperature for the product is between -10℃~60℃.
- Operating or recharging in an environment with a temperature over 45℃ might cause the system malfunction. However, this should be considered a normal phenomenon. Please do not operate under extreme temperatures.

About the altimeter

- The device estimates altitude based on air pressure. Its means that altitude readings for the same location may vary with air pressure changes.
- The semiconductor pressure sensor used by the device for altitude measurements also is affected by temperature. When taking altitude measurements, make sure the device is not subjected to temperature changes.
- Do not use this device for measuring altitude in applications that demand professional or industrial level precision.
- Do not rely upon this device for altitude measurements or perform button operations while sky diving, hang gliding, or riding a gyrocopter where there is the chance of sudden altitude changes.
- The air inside of a commercial aircraft is pressurized. Because of this, the readings produced by this device will not match the altitude readings announced or indicated the flight crew.

Power safety precautions

- Use the power adapter and USB cable that are included with the package. Using other power adapters or USB cables than the one provided will result to malfunction and could proof to be dangerous.
- The device should only be used with the supplied batteries.

About the power adapter

1. Do not use the power adapter in a wet environment. When hands and feet are wet, do not touch the power adapter.
2. While using the power adaptor, ensure that the area is well ventilated. Do not let paper or other material cover the power adaptor, as this will interfere with cooling. Do not use the power adaptor whilst it is in a bag.
3. Do not attempt to repair the device. If device is damaged or is in a wet environment, replace the device immediately.
4. It is not recommended to charge from a PC because the PC power voltage is not

enough to supply the device.

About the battery

1. Use only the original factory approved power adapter.
2. A Lithium battery is built into the device. To prevent fire or skin burns, do not disassemble, pierce, impact, or expose the battery to fire. The battery will crack, explode, or release dangerous chemicals if placed in a fire.

Important instructions

1. Note: Replacing with an incorrect battery may result in an explosion. When disposing of the battery, follow the instructions. The replacement battery must be a factory approved original.
2. Regulations must be observed when recycling or disposing of batteries.
3. The battery should only be used in this device.

Normal care and maintenance

FunTrek130 Pro/ FunTrek130 is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty coverage.

1. If your device does get wet, remove the battery, allow the device to dry completely and then replace the battery.
2. Use a soft clean cloth to wipe the screen.
3. Do not use or store the device in dusty, dirty areas. Accessories can be damaged.
4. Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
5. Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
6. Please do not disassemble the product other than in accordance with the user manual. This may void the warranty and damage the unit.
7. Do not drop, knock or shake the device. Rough handling will break internal circuit boards and fine machinery.
8. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device
9. Do not paint the device. Paint can clog the moving parts and prevent proper operation.
10. Please remember to back up important information such as track log, waypoints, and routes.
11. Sometimes you can reset the device to ensure the best operation status, please turn

off the power and remove the battery.

These proposals are only applicable to FunTrek130 Pro/ FunTrek130, its battery, charger or any other accessories.

Product introduction

Receiver function:

- **GPS Positioning：**Hidden antenna design, high-sensitivity GPS receiver chip can do quick positioning.
- **Electronic compass：**Provides direction for location information, with compass function.
- **Altimeter：**Measure the altimeter by using the GPS altitude and pressure altimeter calibration.
- **Touch screen LCD:** A high resolution color, touch screen TFT LCD with backlight.
- **Water resistant:** IPX6 Waterproof
- **Language support：**Simplified Chinese/ Traditional Chinese/ English
- **Chinese/ English handwriting input:** Support Simplified Chinese/ Traditional Chinese/ English handwriting functions.
- **Memory：**Use micro SD card to store waypoints, routes and navigation map. It is can be used as a removable storage device (flash drive).

Navigation record:

- **Record information：**Store waypoints (including coordinates, altitude etc), track log (including coordinates, altitude etc), and edit routes.
- **Display information：**Contains waypoints, track log, routes, speed, track distance, moving average speed, vertical speed, altitude change, heading, location, reducing the carbon content, and slope, and the other 40 Trip Computer. It also displays the changes on altitude maps information chart.
- **Support Map：**Support all kinds of navigation maps that were developed for FunTrek130 Pro/ FunTrek130.

Outdoor function:

- **Alert setting：**You can set the alert for altitude, speed, distance and time. It can be used for outdoor climbing.
- **ANT+ Heart rate monitor：**With ANT+ heart rate monitor sensor to measure heart rate.
- **ANT+ bike cadence sensor：**With ANT+ cadence sensor to measure cadence.
- **ANT+ bike speed sensor：**With ANT+ speed sensor for bike.

Application functions：

- **G-Finder：** Use the G-Finder feature to calibrate points in order to measure the field area.
- **Coordinate Datum switching：** Support Beijing1954, Xian 80, Taiwan TWD 67, TWD 97 and WGS 1984 coordinates system which are switchable. You also can set more than 250 coordinates.
- **Area calculation：** Measures area for Resources Field Survey.
- **Average location：** Calculate average value of coordinates and average altitude.
- **Other application：** Contains calendar, calculator, stopwatch, and Geocaching.

Electronic map database：

- **Maps characteristic：** FunTrek130 Pro/ FunTrek130 are pre-installed China's (or Taiwan) factory for land-based electronic navigation map on a 2GB microSD card. Its virtual map supports turn-by-turn navigation.
- **Maps characteristic：** The map contents include highway, state and provincial roads, and all other road information; details on the road map of cities across the country generally.
- **Point of Interest (POI) information：** About 5 million in mainland China, Taiwan, more than 310,000 points of interest, including landmarks, attraction, restaurants, gas station all kind of facilities, institutions, information-rich to meet the needs of various types of queries. It supports fast and easy search functions based on the category or the manual text entering query.

FunTrek130 Pro/ FunTrek130 has a variety of GPS applications, not only hiking, bike, also a best partner for car driving to outdoor, which is a convenient tool for the measurement work that is truly full-function handheld product.

Table of Contents

Copyright Declaration ii
Software Copyright ii
Product Caution iii
Product introduction vi
Table of Contents viii
Product Spec 1
- Main program spec 1
- Hardware spec 2
- Unit Overview 3

Basic Operation 4
- Power on and off 4
- Charging Battery 4
- Install/ Remove microSD card 4
- Power on and Positioning 5
- Right button 6
- Left button 9
- Lock/ unlock the screen 11
- Connect to PC 12

Main menu list 14
- Status bar 14
- Main Menu 16

Follow Course 17
- By Track 17
- By Route 18
- G-Finder 19

View Map 20
Managing the Tracks 21
- Search track log 21
- Track Detail 21
- Altitude/ Speed Plot 22
- View Track 22
- Edit track 23
- Delete Track 23
- Copy to new 24
- View multiple Tracks 24

Waypoints 25
- Search waypoints 25
- Waypoint detail 25
- View map 26
- Edit waypoints 27
- Delete waypoints 27

Reposition....27
Average position....28
Copy to new....29
Project to new....29
Application....31
Shortcut....31
Using an External Application....31
Training (FunTrek130 Pro only)....33
Area calculation....37
Geocaching....41
Calendar....43
Alarm clock....43
Calculator....44
Stopwatch....44
Unit Conversion....45
Health....45
Emer. (Emergency info)....45
Tips....46
Routes....46
Settings....50
Personal....50
Sensors....54
System....58
Alerts....66
Profiles....67
About....67
ezTour Plus Installation....68

Product Spec

Main program spec

Item	Spec parameter
Operation interface	Simplified Chinese/ Traditional Chinese/ English/ Czech switching operation
Support external program	Yes
The numbers of waypoints	2000
The numbers of routes	1000
Waypoints of every route	1000
Track log	10000
The total number of sub-record	1000
Record by time interval	Yes
Record by distance interval	Yes
Atomically record	Yes
Continuous recording time	8 hours
Datum	Yes
Beijing 1954	Yes
Xian 80	Yes
Huzih Mountain system	Yes
TWD 67	Yes
WGS 1984 (TWD 97)	Yes
Users define Coordinate Datum	Yes
Coordinate format	Yes
Latitude and longitude	Yes
UTM	Yes
Users define coordinate format	Yes
Computing DGPS differences feature	MSAS, WAAS and EGNOS receiver system

Hardware spec

CPU

- Samsung S3C2416 ARM9 BASE, 400MHz

GPS chip

- High Sensitivity (-159dBm) GPS Chip.

Memory

- 128M Memory
- Built-in 2GB Flash..
- Support SD V2.0

Display

- 3.0 ‘’WQVGA (16:9) TFT LCD
- Transflective Touch Screen (Sunlight viewable)
- 240 x 400 Pixels Resolution

Sensors

- 3D Digital Compass
- Altimeter
- Auto backlight adjustment sensor
- Support 2.4G wireless ANT+^{TM} heart rate straps, bike cadence sensors, bike speed sensors, and combined bike speed/ cadence sensors.

Battery

- 8.5 hrs (on the basis of 50% backlight brightness)
- Rechargeable, Li-Ion 1050mAh

Waterproof

- IPX-6

IO interface

- USB 2.0 (mini USB)

Adaptor

- Input: 100 ~ 240V, 0.15 A, 50~60Hz
- DC output: 5 V, 1A

Dimension:

- 58 x 105 x 23 mm

Weight

- 124g (with battery)

Environment temperature

- Operating Temp: -10℃~60℃
- Storage Temp: -20℃~70℃

Unit Overview

Component Function Description: (Front View)

Item	Description
Touch Screen LCD	The device is using the touch-screen control.
Right button	When the device is powered off, press the right button for 3 seconds to turn on this device. When powered on, press this button for 3 seconds to turn off.
Left button	When the device is powered on, press the left button to switch to the Main Menu, Trip Computer page and Navigation.
LED	1. The LED flashes red when charging 2. The LED stop flashing but lights on when charging is complete. 3. The LED dims when the USB is unplugged. 4. The LED will first light on a second, and the opening screen appears on the screen.

Component Function Description: (Rear View)

Item	Description
Battery lid	Press and push to open the battery lid for installing or replacing batteries.
Screw holes	Fix and secure screws.

Component Function Description:

Item	Description
USB port	Connect power or PC/NB for charger or data transfer.
Stylus Lanyard	You can attach the bundled stylus to the device.



Front View

Back View



Low Rear View

Basic Operation

Power on and off

When device is turned on, press and hold the right button for 3 seconds to power off the device. The prompt "Saving data… please wait." will appear while the device is powering off. When device is turned off, press and hold the right button for 3 seconds to power on.

Note: Please do not power off the devices when you use the "Training" or "Area calculation" functions, the track log can't be saved normally.

Charging Battery

You may choose one of the following methods to charge the device.

1. Connect the USB adapter to a wall outlet.



2. Connect the USB cable to your computer. For details, please refer to the charging mode
3. If the supplier includes with a car power adapter, plug the respective ends of the device to the card cigarette lighter and the USB cable interface in order to charge the device.

Install/ Remove microSD card

Step:

1. Open the battery lid and remove the battery.
2. Insert microSD with its chip facing down and flat into the microSD slot and push upward to lock the microSD card slot.
3. To remove the microSD card, unlock the SD socket and remove the SD card.

Power on and Positioning

First positioning

Please take the device out of the room, and turn on the device. Then enter into the satellite status page to displays the position status. When searching satellite signal will display “Acquiring”. “2D Fixed” means the positioning status mode. “3D fixed” means the coordinate information is available for reference.

Only after the positioning is successfully for the first time, it will begin to record the track.

General positioning

Once starts up, it will automatically do the positioning.

Satellite status page



Right button

Backlight

Step:

- Press the right button once to enter the operation page as shown above.
- Click the button to increase/decrease the backlight brightness.

Auto Light

FunTrek130 is equipped with a sensor that automatically detects the ambient light level and adjusts the backlight brightness to save power.

Step:

- Press the right button once to enter the operation page.
- Select in the backlight adjustment area and the backlight brightness will be automatically adjusted to suit the ambient light.

New Track

Step:

- Press the right button once to enter the operation page.
- The middle area of the screen shown as is the operation area.
- Automatically record: Users have to complete the satellite positioning and altimeter

calibration when they first powered on. The device will record track log automatically.

- Manually record: press the button to enter the new a track log. On the page, users can edit name, notes, and view sport modes.
- Press the button to save the track log, and start to record.
- Press the button to pause recording; press the button to start/continue recording.
- Press the button to stop recording, and save the track data.

Note:

- ✧ *Track log name can be input up to 20 words, notes can be input up to 50 words.*
- ✧ *When device is manually powered off, the track log will be automatically saved.*
- ✧ *The track log will be lost if power is accidentally interrupted or the battery is removed after a crash.*

New checkpoint

After adding a track, you can create a checkpoint on the track.

Step:

- Press the right button once to enter the operation page.
- The right bottom of page is the area to mark checkpoint. Press the button to enter the checkpoint edit page. You can edit checkpoint name, add notes, edit checkpoint coordinates location and input checkpoint altitude.
- Click “location” button to define the checkpoint coordinates. Press the button to set coordinates formate and system. Press the button to save the coordinates edit result.
- Click “altitude” button to define the altitude information of checkpoint Press the button to save the altitude editing result.
- When completed, return to checkpoint edit page, and press the button to save checkpoint information.

Note: Checkpoint name can be input up to 20 words, notes can be input up to 50 words.

New waypoint

Step:

- Press the right button once to enter the operation page.
- The bottom of page is the area to mark waypoints . Press the button to enter the waypoint edit page. You can edit waypoint name, select waypoint symbol, add notes, edit waypoint coordinates location and input waypoint altitude.
- Click “location” button to define the waypoint coordinates. Press the button to set coordinates formate and system. Press the button to save the coordinates edit result.
- Click “altitude” button to define the altitude information of waypoints Press the button to save the altitude editing result.
- When completed, return to waypoints edit page, and press the button to save waypoints information.

Note: Waypoint name can be input up to 20 words, notes can be input up to 50 words.

Left button

Trip Computer

Step:

- Press the left button once to enter the Trip Computer.
- In the Trip Computer page, you can view travel distance, travel time, current speed and altitude, and the other 40 Trip Computer.
- Use the button to check more navigation data.

Change Trip Computer Items

Step:

- Press the setting button . You can select the item that you want to change. Click the item to enter the Trip Computer list, and use the up/down button to flip page and search.
- Select the item to be added, press confirmation button to change.

Page Display Selection

In the Trip Computer, press the button. You can use the and buttons to change the number of pages displayed on the screen.

: displays 3 items of Trip Computer on screen.

: displays 8 items of Trip Computer on screen.

View statistical curve

FunTrek130 Pro/ FunTrek130 can record the height, speed, pressure, time and distance curve for the user to view the analysis.

Step:

- Press the left button once to enter the Trip Computer.
- Press the button, and enter the statistical curve page.
- Click the two trip information areas on the top of page, you can switch the item. You can select from the items: “Time”, “Location”, “ALT”, “Speed”, “Heart Rate”, “Cadence” and “Air Pressure”.
- Press the button to switch axis. User can select the axis item to display to the altitude, speed, Heart Rate, Cadence, pressure chart according to its changes with time or distance.
- Use the and buttons to zoom in and zoom out the altitude chart.
- When you change the graph scale, use to return normal status.

Note: If you didn't record track log, the device doesn't have the altitude, speed, and pressure information and it also doesn't display the statistical curve.

Compass



Step:

- Press the left button once to enter the Trip Computer.
- Press the button to enter compass page. On the compass page, you can view current direction, azimuth and compass.
- Compass which has not done with its calibration can not accurately show the direction. Press the button to calibrate the compass. For details, please refer to the Compass.

General information

Step:

- Press the left button once to enter the Trip Computer.
- Press the button to enter general page. Users can view GPS coordinates information, GPS signal strength, DOP and Time.

Lock/ unlock the screen

If the screen is unlocked, press the left button for 3 seconds to lock the screen, the message of "Screen locked" appears on the screen. The “unlock" message pops up on the screen if press the left button for 3 seconds. Once the screen is locked, press the left button for 3 seconds to unlock the screen.

Connect to PC

When the FunTrek130 Pro/ FunTrek130 is connected to a PC, the following prompt will appear. You can choose to enter storage mode or charging mode.

Read the microSD card data

Connect FunTrek130 Pro/ FunTrek130 to the PC with a USB cable and turn on the device. When the prompt appears, click to enter storage mode.

Note: Press the left button to start the navigation. If the navigation does not appear on the screen, do not plug in the USB cable.

Folders

In Storage mode you will be able to see the folders in the memory card.

Folder Name	Description
bg	Stores background pictures. The user can add or delete pictures in this folder.
map	Stores the navigation program.
sc	Store screenshot pictures.
track	Stores track files. The user can add or delete tracks in this folder.
route	Stores route files. The user can add or delete route in this folder.
wpt	Stores waypoint files. The user can add or delete waypoints in this folder.
update	Stores applications.
cache	Maps collection
hmp	Customized map

Charging mode

Connect FunTrek130 Pro/ FunTrek130 to the PC with an USB cable. When the prompt appears, click to enter charging mode. When the device is power off and connect to the PC, enter charging mode.

Screenshot



FunTrek130 Pro/ FunTrek130 can take a screenshot and save as a picture. Press both the left and right buttons at once to take a screenshot. If screenshot is successful, a prompt will appear. When the FunTrek130 Pro/ FunTrek130 is connected to a PC in storage mode, the saved screenshot can be accessed in the "sc" folder.

Note: Do not use the capture screen function when the screen is locked.

Main menu list

When the device turned is on, the status bar is displayed on the top of main menu. The six icons are function lists in below of main menu.



Status bar

Satellite information

Icon	Description	Operation
/	The signal strength / GPS positioning	Click the icon to enter the satellite page

Time

Icon	Description	Operation
	Time information	Click the icon to enter
	Alarm is turned on	Click the icon to enter. Please refer to Alarm.
	Alarm is turned off.	Click the icon to enter. Please refer to Alarm.

Note：GPS positioning should be enabled to ensure that the correct time is displayed.

Power message

Icon	Description	Operation
	Power message	Click the icon to enter.
	Battery down to 45% charge	Click the icon to enter.
	Battery down to 30% charge	Click the icon to enter.

Storage mode

Icon	Description	Operation
	Track and waypoint data stored in microSD card.	Please refer to Storage media
	Track and waypoint data store in internal memory.	Please refer to Storage media

Heart rate monitor (HRM) (FunTrek130 Pro only)

Icon	Description	Operation
	HRM sensor is turned on.	Please refer to Heart Rate Monitor
	HRM sensor is turned off.	Please refer to Heart Rate Monitor

Cadence (FunTrek130 Pro only)

Icon	Description	Operation
	Cadence sensor is turned on.	Please refer to Cadence
	Cadence sensor is turned off.	Please refer to Cadence

Compass

Icon	Description	Operation
	Compass calibrated	Please refer to Compass
	Compass requires calibration	Please refer to Compass

Alarm clock

Icon	Description	Operation
	Alarm is turned on.	Please refer to Alarm
	Alarm is turned off.	Please refer to Alarm

Backlight

Icon	Description	Operation
	Backlight is on.	Please refer to Backlight
	Backlight is off.	Please refer to Backlight

Locked the screen

Icon	Descript	Operation
	The screen is locked.	Please refer to Screen Lock/ Unlock
	The screen is unlocked.	Please refer to Screen Lock/ Unlock

Track log

Icon	Descript	Operation
	The track log was recording.	Please refer to New Track
	The track log was paused.	Please refer to New Track

Main Menu

The main menu contains four shortcuts, Application and Settings. For shortcut items can be set, the default is “Follow Course”, “View Map”, “Tracks”, and “Waypoints.

Follow Course

With Follow Course function, it can guide you to your pre-defined destination. The available options are “By track”, “By route” and “G-Finder”.

By Track

When selecting the saved track, you can set several locations as ”Starting”, “Ending” or “Check point” waypoints. And the waypoint location can be switched.



Step:

- On the main menu, click “Follow Course” to enter the waypoint menu.
- Click “By track” icon to enter the track waypoint menu.
- On the track list, select the desired track record.
- Select ”Starting”, “check point” or “Ending”, then select a location on the track as a waypoint.
- After all settings are completed, it will display the G-Finder information.
- Press the button to view G-Finder screen.
- Press the button to import the customized map.

Note:

✧ If the last location in the waypoints need to be set as the starting point, press you press to switch the current location to be the starting point.

✧ To import maps, refer to “Customized Map” section.

By Route

When selecting the saved track, you can set two waypoints as “Start point” or “End point”.

The selected track can be set as the destination of designated waypoints, and these two waypoints location can be switched.

Step:

- On the main menu, click “Follow Course” to enter the waypoint menu.
- Click “By route” icon to enter the track waypoint menu.
- On the track list, select the desired track record.
- Select “Route name”, and set “waypoint name” position as the waypoint.
- After all settings are completed, it will display the G-Finder information.
- Press the button to view G-Finder screen.
- Press the button to import the customized map.

Note:

✧ If the last location in the waypoints need to be set as the starting point, press you press to switch the current location to be the starting point.

✧ To import maps, refer to “Customized Map” section.

G-Finder

The G-Finder enables users to mark their starting points. It helps you get the current position and distance from where you started. This helps guide you to return to the starting point.

Step:

- On the main menu page, click “Follow Course”.
- Click “G-Finder”.
- Press the button to enter G-Finder points list.
- “Current position”: Current location will be set as the G-Finder point.
- “User define”: Input coordinates value of the G-Finder point.
- “Waypoint”: Select waypoint of the G-Finder point.
- After all settings are completed, it will display the G-Finder information.



- Press the button to view G-Finder screen.
- Press the button to import the customized map.

Note: If GPS has not completed the positioning, the information will not be displayed.

View Map

With the map view, user can browse the tracks, waypoints, routes and areas. Following are the map features:

- Press the button to zoom in/out on the map.
- Adding marker on the map: Press the button to mark the location on the map. Press the button again to locate the position in the middle of the screen which makes it easier to browse.
- Press the button to set the center of the screen position.
- If you have created your own map on the device, press button and select the map name, then you can enter the map screen.
- Press the button to set the display including the three options: “North up”, “Front up” and “Course up”.
- North up: Maps of the northern part.
- Front side: Equipment for the Northern direction.
- Course up: Navigate direction up.
- The track will show following status:
  - ■ - the location is unknown.
  - ■ - the location is found and at idle state.
  - ■ - it is moving, and the direction of the movement is indicates by the direction of the arrow.
  - ■ - the starting point of the path or route, - the end of the track or route.

Note:

✧ To import maps, refer to “Customized Map” section.

✧ Customized map can be used to import tracks, waypoints, routes, or testing area as the map background.

Managing the Tracks

With Track management, you view, edit, or copy the track, or get the detail information of each track log. You can also search for a particular track.

Notes: The recording log will automatically stop when the recording time or distance reaches its maximum limit.

Search track log

Step:

- On the main menu page, click “Tracks” to enter the track list.
- Press the button to enter the input page. Enter the track log name or keywords.
- After completed, press “confirmation” button to display the search result.

Note: After search, if you exit the track management, it will no longer display the search results page. Next time, enter the track management page to view all track lists.

Track Detail

Step:

- On the main menu page, click “Tracks” to enter the track list.
- Select the track that you will operate, click to enter the Track Menu.
- Select “Detail”. Details vary with the different modes such as walking mode which

includes the amount of carbon reduction, the tree planting quantity. The car mode does not include the same functions as walking mode.

Note:

✧ *If you edit sport mode, press the* *button to refresh the track information.*

Altitude/ Speed Plot

With Altitude map, you can playback the track record to view the changes of the altitude.

Step:

- On the main menu page, click “Tracks” to enter the track list.
- Select the track that you will operate, click to enter the Track Menu.
- Click “Altitude/ Speed Plot” to enter the altitude page. After drawing graphics, you can zoom in/out and drag the graphic, view the altitude, speed, time, coordinates, and air pressure.
- Click the two trip information areas on the top of page and you can switch those items. You can select “Time”, “Location”, “ALT”, “Speed”, “Heart Rate”, “Cadence” and “Air Pressure” item.
- Press the button to switch axis. User can select the axis item to display to curve.

View Track

Step:

- On the main menu page, click “Tracks” to enter the track list.
- Select the track that you will operate, click to enter the Track Menu.
- Select “view map”, the screen will display the track. You can zoom in or zoom out to change the scale. The track name is shown on the top of the screen. Press the button to set the map display direction.



- Press the button and click the location on the map to mark a point.
- Press the button to move the point to center of the screen.

Edit track

Step:

- On the main menu page, click “Tracks” to enter the track list.
- Select the track that you will operate, click to enter the Track Menu.
- Select “Edit” to edit track name, notes and sport modes.
- If you change the sport mode, press the button to refresh the track information.

Delete Track

Step:

- On the main menu page, click “Tracks” to enter the track list.
- Select the track that you will operate, click to enter the Track Menu and select “Delete”.

Copy to new

Step:

- On the main menu page, click “Tracks” to enter the track list.
- Select the track that you will operate, click to enter the Track Menu.
- Select “Copy Track” to enter the edit track page.
- Press the confirmation button to copy.

View multiple Tracks



Step:

- On the main menu page, click “Tracks” to enter the track list. Check the tracks you want to display.
- You can select up to three tracks to be displayed at one time.
- Select one of the tracks, you can still view multiple tracks on the map.

Note:

- ✧ *The FunTrek130 Pro/ FunTrek130 stores one track per GPX file.*
- ✧ *If a GPX file with multiple tracks is downloaded from the Internet, FunTrek130 will display them as one single track.*

Waypoints

Search waypoints

There are plenty of destinations that you can choose. Use the search function to quickly find the desired destination.

Step:

- On the main menu page, click “Waypoints”.
- Click the button to enter the input method page. Enter the key words of the waypoints.
- Press the confirmation button to display the searching results.

Note: After search, if you exit the waypoints management page, it will no longer display the search results. Next time, enter the waypoints management page to view all waypoints lists.

Waypoint detail



Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select “detail” to view the detail information of the selected waypoint.

View map

Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select "Browse”, the screen will display the waypoint position.



- Press the button and click the location on the map to mark a point.
- Press the button to move the point to the center of the screen.

Edit waypoints

Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select “Edit” to enter the waypoint edit page. You can edit waypoint name, select waypoint symbol, add notes, edit waypoint coordinates location, and input waypoint altitude. On “Coordinates input” page, press the button to set the condinates format and system.
- Press the confirmation button to delete.

Delete waypoints

Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select “Delete”. The confirmation message appears on the screen.
- Press the confirmation button to delete.

Reposition

With reposition, you can use the current point to replace the original coordinates with the updated waypoints coordinates.

Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select “reposition” to update the waypoints coordinates to the current location coordinates.
- When repositioning is completed, a message appears on the screen. Press the "confirm" button.
- If GPS does not acquire the satellite signal, the device can not repositioning.

Average position

“Average position” calculates the average value of altitude the GPS sampling points and coordinates information in order to obtain the accurate values on both altitude and coordinate information.



Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select “Average position” to calculate current position and altitude.
- When you have achieved the required sampling, press the button to enter waypoint edit page. The waypoints’ coordinates value are replaced with the average coordinates value.

- On the edit page, press button to save the waypoint information.

- Press the button to calibrate altimeter by average altitude.

On the Location map of 10 meters, 20 meters or 30 meters radius, when the sampling point is focused on the center, the average coordinate value is closely paralleled the true value.

On the Altitude map, the height value is the horizontal axis, and the origin of the horizontal axis is the average height. When the sampling point is achieved, the average altitude value is closely paralleled the true value (as shown on the first illustration above). If the same circumstances, if there is a sudden altitude changes, the altitude reading will be inaccurate. It is recommended to measure it again when the GPS signal and situation are in better conditions.

Copy to new

Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select “Copy a new” to enter the waypoint edit page. You can edit waypoint name, select waypoint symbol, add notes, edit waypoint coordinates location, and enter waypoint altitude. On “Coordinates input” page, press the button to set the condinates format and system.
- Press the button to save the new waypoints.

Project to new

“Project to new” is the origin to a waypoint, enter the distance and azimuth to create a new waypoint.

Step:

- On the main menu page, click “Waypoints”.
- Select the point that you will operate, click to enter the Waypoints menu.
- Select “Project to new” and enter the distance and bearing. Press the button to save.
- Enter a new waypoint edit page, a confirmed coordinates and altitude information. Press the button to create a project waypoint.

Application

Application contains all main functions of FunTrek130 Pro/ FunTrek130.

Shortcut

All functions in application page can be set as shortcuts on the main page.

Step:

- On the main menu page, click “Application”.
- Press the button to enter function list.
- Select the function that you will set as shortcut, and click to enter shortcut list. Select the location of the shortcut, and return to the application page.

Using an External Application

User can add any third party navigation software developer (either from other countries or regions) into FunTrek130 Pro/ FunTrek130.

For example, SmartMaps installation:

- Connect the device to the computer by using the USB cable. On the Storage Card (or SD card), create an “app” folder. The same operation steps applied to Storage Card or SD card.
- To install the third party software, copy the related file to the “Storage\app” folder.



- In the “Storage Card\app” folder, place the SmartMaps icon which is in PNG format. For example, the filename is “smartmaps.png”. In the main menu, this icon represents the third party software’s icon.
- In the “Storage Card\app” folder, create an INF file for SmartMaps. For example, “smartmaps.0409.inf”. Refer to the following guideline:

  name=SmartMaps

  icon=\Storage Card\app\smartmaps.png

  exec=\Storage Card\app\SmartMaps\smartmapspna.exe
- To start using the application, launch SmartMaps on the “Main menu/Programs”.

Note：

✧ *Basically, user can execute the exe program and PNG images on any storage location on FunTrek130 Pro/ FunTrek130. Be sure that the inf file contains the correct path for name, icon, and exec.*

✧ *Inf file information:*

“name=SmartMaps ” – the third party software name to be displayed on the main menu. If not specified, it will be displayed as a “shortcut”;

“icon=\Storage Card\app\smartmaps.png ” – the third party software icon in the main menu. If not specified, or specify with the wrong path, the default short icon is FunTrek130 Pro/ FunTrek130;

“exec=\Storage Card\app\SmartMaps\smartmapspna.exe ” – the execution location. If it is not specified or specify with the wrong path, the third party software will fail to launch.

✧ *Inf file is a setup file. You can create a txt text file, edit and save the file. Rename the txt file to inf file format.*

- ✧ *Inf file naming convention is the "Software name, Language ID number". Language ID number have to cooperate with FunTrek130 Pro/ FunTrek130 languages. If FunTrek130 Pro/ FunTrek130 main program is the Simplified Chinese version, the inf file name should be "Software Name .0804." (in Simplified Chinese). If the third-party software operating language is English, and FunTrek130 Pro/ FunTrek130 main menu displays third-party software in Simplified Chinese names. Then English is used for the third-party software operation. If the language ID number and FunTrek130 Pro/ FunTrek130 language does not match, an error will occur when running the third-party software.*
- ✧ *0409 is 4-digit language ID that represents American English, 0804 represent Simplified Chinese, 0404 represents Traditional Chinese.*

Training (FunTrek130 Pro only)

Connect your FunTrek 130 Pro with the follow ANT+ sensors: heart rate, bike cadence, bike speed and/ or combined bike speed and cadence..

Note: Before you use the Training function, please do the positioning first.

Please do not power off the device when you operate "Training" function, the track log can't be saved normally.



Step:

- On the main menu page, click "Application".
- First connect heart rate monitor, bike cadence and bike speed sensor. Details reference for ANT+ Heart Rate Monitor, ANT+ Bike Cadence Sensor and ANT+ Bike Speed Sensors sections. After connected, it starts to receive the data. Click "Training" button to enter the training page.
- "HR Grade": Before you set the HR grade, please read the message that appears on the screen. Press the button to enter HR Grade list and select the appropriate heart rate range.


Best Cadence not refer to most efficient energy used, but refer to Cadence that cause less neuromuscular fatigue. Please consult your personal trainer for the best Cadence that fit your training.
Page 1/1
1(40-59rpm)
1(40-59rpm)
1(40-59rpm)
1(40-59rpm)
User Define
Please input min Cadence...
12
Please input max Cadenc...
20

- "Cadence Grade": Before you set the Cadence grade, please read the message that appears on the screen. Press the button to enter cadence grade list and select the appropriate cadence range.
- Users can define the cadence range. Click "User Define" to enter the minimum cadence value and press the "confirmation" button. Next, enter the maximum cadence value and press the "confirmation" button to save.
- "Training Time": Enter the training time, and then press the "confirmation" button to save.

- Click "Last Training" to view the detail information of last training. It only displays the results of the recent training. To view more information, press .
- "New Training": Enter training page.



- The training information page displays heart rate, cadence rage, speed, and training time, etc.

Note: The heart rate or cadence which is currently lower than the preset minimum value is displayed in green, higher than the preset maximum value is shown in red, and displayed in white within the default display.

The training information page is based on the connection situation, then display different status:

- The sensor is disconnected, it displays as "---";
- The sensor is connected and the signal is good, it displays the data and the icon is blinking;
- The sensor is connected, but the signal is poor and the display data shown is below than the minimum value for 1 to 5 seconds, cadence and speed data decreases, the icon does not blinking;
- The heart rate data is displayed as the last time, the icon does not blinking;
- The sensor is connected, but the signal is poor or the display data shown is low for 6 seconds to 1 minute, cadence and speed data are 0, and the icon is not blinking. The signal data is displayed as "???", the alert beep is on in every 10 seconds;
- The sensor is connected and the poor signal lasts more than 1 minute, the cadence, speed and heart rate are displayed as "---".

FunTrek130 Pro/ FunTrek130 training information range is: Heart rate 30-220bmp, Cadence 20-255rpm, Speed 2.4-244km/h.

Cadence, speed and heart rate data which are higher than the maximum value, the display will continue to show the maximum value.

- On the training information page, press the button to flip to the HR or Cadence graphics page. Press the button to switch axis. In the graphics, the dark horizontal bands is the setting rage of heart rate/cadence. Browse the charts for reference.
- Click the heart rate/cadence chart at the top of the "altitude" or "speed" block to enter the information option lists. Select different information to display on the chart.



- In training process, press the "Back" button and a message appears on the screen. Press the button to exit the training, or press the button to continue training.
- When training is completed, pops up the training is finished. Press the button to ends the training and saves records. User can view multiple training records in the track management.



- “Last training”: You can review the detail information of last training. Press the button to refresh the information.

Area calculation

Area calculation can immediately measure the area, and the routes can be saved as a track log.

Available options are “By track”, “By vertices”, and “By fixed-width”.

By track

The track size is measured by the track length. To calculate the length, trace the route of the track log until the end and return back to the starting point.

Step：

- On the main menu page, click “Applications” to enter the Program menu.
- Click “Area” icon to enter the area calculation page.
- Select “By track” and press button to enter track display page.
- When completed, press the button to display the measure of the track area.
- Press button to complete and save the result.

- On the length/area unit page, press the button to change the unit of length/area. Click “Unit of length” or “Unit of area” button to enter the unit list. Users can click one of the unit buttons to “Move down”, “Insert before”, “Insert behind” and “Delete” the unit. On this page, press the button to add other units.



- Click “Price of length” or “price of area” button and input price of length/area. You can view the total price of length/area on the track log display page.
- Press the button to save the track, and press the “OK” button to save the track log.

Note: Please do not power off the device when you use the “Area Calculation” function, the track log can’t be saved normally.

By Vertices

Manually set vertices points to calculate the area enclosed by the vertices.



Step：

- On the main menu page, click “Applications” to enter the Program menu.
- Click “Area” icon to enter the area calculation page.
- Select “By vertices” and press button to enter track display page.
- At each vertex point, press button to manually obtain the average surface area.
- After determine several coordinates, press button to return to track; indicates that the setup has been completed.
- When completed, press the button to display the measure of the track area.
- Press button to complete and save the result.

Note: If only one vertex is assigned, set the number of coordinates to 1. If 10 vertices are assigned, set the number of coordinates to 10. The system will then automatically calculate the average to obtain the average surface area.

- On the length/area unit page, press the button to change the unit of length/area. Click “Unit of length” or “Unit of area” button to enter the unit list. Users can click one of the unit buttons to “Move down”, “Insert before”, “Insert behind” and “Delete” the unit. On this page, press the button to add other units.



- Click “Price of length” or “price of area” button and input price of length/area. You can view the total price of length/area on the track log display page.
- Press the button to save the track, and press the “OK” button to save the track log.

By fixed-width

Enter the width length to calculate the track area to the destination. With the track distance and width length, the size of the area can be calculated.



Step：

- On the main menu page, click “Applications” to enter the Program menu.
- Click “Area” icon to enter the area calculation page.

- Select “By fixed-width” icon.
- Click “Width” and “Unit” to input the width length and its measurement unit.
- Press button to enter track display page.
- Press button to enter again “Width” and “Unit”.
- When completed, press the button to display the measure of the track area.
- Press button to complete and save the result.

- On the length/area unit page, press the button to change the unit of length/area. Click “Unit of length” or “Unit of area” button to enter the unit list. Users can click one of the unit buttons to “Move down”, “Insert before”, “Insert behind” and “Delete” the unit. On this page, press the button to add other units.



- Click “Price of length” or “price of area” button and input price of length/area. You can view the total price of length/area on the track log display page.
- Press the button to save the track, and press the “OK” button to save the track log.

Geocaching

Visit www.geocaching.com website to download the geocaching documents.

Information

The information includes “Difficulty”, “Terrain”, “Cache Size” and “Trackable” and Hints.

Step:

- On the main menu page, click the “Applications” icon to enter the Program menu.
- Click the “Geocaching” icon. The cache that has been found will be marked as , contrarily, it is marked as .
- Click Geocaching to view the information.

Note: The FunTrek130 Pro/ FunTrek130 can store up to 500 cache locations.

GeoRadar

Step:

- On the GeoRadar page, press the button to view the GeoRadar information.
- Press to mark the cache that has been found and added notes. If you don’t add any note, it returns to the GeoRadar page directly.

Compass

Step:

- On the GeoRadar page, click button to view the compass information.
- Press the button of compass bottom page to return information page.

Mark Found

Step:

- On the GeoRadar page, press the button to mark found.
- Press the button to mark not found.

Add Geocaching Notes

Step:

- On the Compass page, press the button to mark found and add notes.
- After adding the comments, it returns to the GeoRadar page.

Calendar

Step:

- On the main menu page, click “Applications” icon to enter the Program menu.
- Click “Calendar” icon to view the calendar page. Use the button to change month.

Alarm clock

Step:

- On the main menu page, click “Applications” icon to enter the Program menu.
- Click “Alarm clock” icon to enter the Alarm clock page.
- Press the Alarm Off button to turn on the alarm clock.
- Press the button to save the value.
- Press the Alarm Off button to turn off the alarm clock.

Note:

- ✧ *When setting the alarm, do not select a date. When the alarm is on, the system will only ring once on the set alarm. If you set the alarm earlier than the current time, it will ring on the next alarm.*
- ✧ *When the alarm is ringing, select “keep repeat”, it will ring again after 10 minutes. It can be repeated 6 times.*
- ✧ *When the device is power off, the alarm clock is still work. However during the power charging time, the alarm clock will not work.*

Calculator

Step:

- On the main menu page, click “Applications” icon to enter the Program menu.
- Click “Calculator” icon to enter the Calculator page.

Note:

✧ *Input with up to 13 digits can be entered into the calculator.*

✧ *If the result exceeds 13 places, it will be displayed using scientific notation.*

Stopwatch



Step:

- On the main menu page, click “Applications” icon to enter the Program menu.
- Click “Stopwatch” icon to enter the Stopwatch page.
- In timing process, users can pause or continue timing.

Unit Conversion

Step:

- On the main menu page, click the “Applications” icon to enter the Program menu.
- Click the “Unit” icon. Users can converts units of length, area, weight and volume.
- Click the input box and enter the value that you want to convert. You can do two conversions at one time.
- Click unit name to convert units.

Health

Step:

- On the main menu page, click the “Applications” icon to enter the Program menu.
- Click the “Health” icon.
- Select one of the options, click it to enter and view the Health Info.

Emer. (Emergency info)

Step:

- On the main menu page, click the “Applications” icon to enter the Applications menu.
- Click the “Emer.” icon to enter browser page.

Tips

Tips function can help user to understand FunTrek130 Pro/ FunTrek130 and GPS knowledge. The default is displayed at power on. Users can view all tips content in application function.


Authorized by the United State
s government, the US DOC (De
partment of Defense) develops
and manages GPS and is respo
nsible for the operation and pe
rformance of the system.
Based on the national security
strategy, the US DOD claims th
e exclusive right to change the
GPS system and accordingly th
e function and accuracy of GPS
without prior notice or announ
cement.

Step:

- On the main menu page, click the “Applications” icon to enter the Applications menu.
- Press the “Tips” icon to view the contents.

Routes

You can use waypoints to build routes, and edit routes name, description, and points.

New routes

Step:

- On the main menu page, click “Routes”.
- Press the button to enter a new routes page.
- Click “points” to enter the point list. Click the button to select waypoints add into the routes. User can selects single or multiple waypoints.
- After added waypoints, return to new routes page. Press the button to save the routes.

Notes：

- ✧ *Waypoints mean the route destinations.*
- ✧ *Routes name can be input up to 20 words, notes can be input up to 50 words.*

Details

The details information contains name, length and area.

Step:

- On the main menu page, click “Routes”.
- Select the route that you will operate, click to enter the Routes Menu.
- Select “Details” to view the detail information of the selected route. After you have reached the destinations, user can view the route name, comments, starting destinations. The starting and ending points link to a closed areas perimeter and dimension, and the route creates the changes of date and time.

View map



Step:

- On the main menu page, click “Routes”.
- Select the route that you will operate, click to enter the Routes Menu.
- Select “View map”.

Edit



Step:

- On the main menu page, click “Routes”.
- Select the route that you will operate, click to enter the Routes menu.
- Select “Edit” to enter the route edit page. You can edit route name, add notes, edit route points.
- Click “Points” to enter point list. Click the point that you will operate to enter the point operation menu. On this page, you can “forward”, “backward”, “insert” and “delete” the points. Click the button to select waypoints to add into the routes.
- Coordinates location and enter the waypoint altitude. On “Coordinates input” page, press the button to set the condinates format and system.
- After edit waypoints, return to new routes page. Press the button to save the routes.

Delete

Step:

- On the main menu page, click “Routes”.
- Select the route that you will operate, click to enter the Routes menu.
- Select “Delete” button and then a deletion confirmation message appears on the screen. Press the button to delect the route.

Copy to new



Step:

- On the main menu page, click “Routes”.
- Select the route that you will operate, click to enter the Routes menu.
- Select “Copy a new”, you can copy a new route name, description, and points.
- After editing, press the button to copy a new route.

Reverse to new

With “Reverse to new” function, you can create a route in the opposite direction with the original route.

Step:

- On the main menu page, click “Routes”.
- Select the route that you will operate, click to enter the Routes menu.
- Select “Reverse to new” to enter the route edit page.
- Press the button to create an opposite route.

Settings

Personal

The Profile function contains “Odometer”, “Track Log”, “Age & Weight”, “Background” and “Customized Maps”.



Odometer

You can save trip information in ODO1 or ODO2.

Step:

- On the main menu page, click Settings.
- Select “Personal” to enter you personal settings list.
- Select “Odometer” to enter “ODO1” or “ODO2”.
- The default value is “ODO1”.

Note: “ODO1” and “ODO2” are the same functions that can save the trip information.

Track Record

Manually/ Automatically record track

User can set the track record mode, select start tracking manually or automatically, and track the interval recording time.



Step:

- On the main menu page, click Settings.
- Select “Personal” to enter your personal settings list.
- Select “Track Log” to enter the track log mode.
- Select “Manually” or “Automatically”. If "Manually" is selected you must use the right button to create a new track in order to begin recording.
- After restart the device, the new setting will be applied.

Log Interval

Select time or distance for log interval.

Step:

- On the main menu page, click Settings.
- Select “Personal” to enter your personal settings list.
- Select “Log Interval” to open the menu. The two options are "Distance" and "Time".

- Select "Distance" or "Time" to enter the enable/disable menu.
- Select “Enable” to enter the time or distance interval.
- When completed, press the confirmation button.

Age & Weight

Step:

- On the main menu page, click Settings.
- Select “Personal” to enter your personal settings list.
- Select “Age & Weight” to enter the personal information list.
- Select each item in turn to enter appropriate information.
- When completed, press confirmation button to save your setting.

Background

Step:

- On the main menu page, click Settings.
- Select “Personal” to enter your personal settings list.
- Select “Background” to enter the “Background” menu.
- You can add pictures to the list by loading the picture files to the “bg” file folder.

Note: FunTrek130Pro only supports the “bmp” file format and the best resolution is 240×400 pixels.

Create Map

FunTrek130 Pro/ FunTrek130 supports the Convert Tool to transfer smd map file, which enables user to create a new smd map to be added in the device.

Steps:

- Use Convert Tool to convert bmp, jpg, and other map images into smd map. Please refer to the Convert Tool's user manual.
- In the Holux device or SD card, create a folder name "hmp".
- Place the converted smd file into the "hmp" folder, and start the FunTrek130 Pro/ FunTrek130.
- On the main screen, click "Setting", select "System Setting".
- Use the arrow keys to browse, select "Create Map", and then enter the Create Map menu.
- Click on the map that you want to add, or you can view the converted map while browsing the map. You can also close the new map.

Note:

- ✧ *To use Convert Tool to convert the image files (bmp, jpg, etc) into "smd" map image, please refer to Convert Tool user's manual.*
- ✧ *To zoom in/out the map, you need to convert some images with different sizes into one smd map.*
- ✧ *If you only convert to one size picture into the map, you cannot zoom in/out when browsing the map.*

Sensors

Sensors contain “ANT+ Heart Rate Monitor”, “ANT+ Bike Cadence Sensor”, “ANT+ Bike Speed Sensor”, “Compass”, “Altitude” and “Screen”.

ANT+ Heart Rate Monitors (FunTrek130 Pro only)



Search heart rate monitor sensor, the steps are:

- On the main menu page, click Settings.
- Select “Sensor” to enter the sensor settings menu.
- Select “Heart Rate Monitor”, and press the “Search” button.
- After searching match heart rate monitor sensor, the device will display the list.
- Select the heart rate sensor that you need, and press the confirmation button to enable the function. The heart rate information will be displayed on the left-key info page.
- Users can enable or disable the sensor.



The details page displays the sensor's information, such as S/N number; manufacture ID, model number, hardware version, software version and R-R Interval.

The model number of Heart Rate Monitor sensor is 10.

ANT+ Bike Cadence Sensors (FunTrek130 Pro only)



Step:

- On the main menu page, click Settings.
- Select "Sensor" to enter the sensor settings menu.
- Select "Cadence Sensor", and press "Search" button.
- After searching match cadence sensor, the device will display the list.
- Select the cadence sensor that you need, and press the confirmation button to enable the function. The cadence information will be displayed on the left-key info page.
- Users can enable or disable the sensor.



The details page displays the sensor's information, such as Serial number; manufacture

ID, model number, hardware version and software version.

The model number of Cadence sensor is 20.

ANT+ Bike Speed Sensors (FunTrek130 Pro only)



Step:

- On the main menu page, click Settings.
- Select “Sensor” to enter the sensor settings menu.
- Select “Speedometer”, and press “Search” button.
- After searching match speed sensor, the device will display the list.
- Select the speed sensor that you need, and press the confirmation button to enable the function. The speed information will be displayed on the left-key info page.
- Users can enable or disable the sensor.
- User can calculate the wheel speed by specifying the wheel size. Please select the appropriate wheel size from option lists or enter the specific wheel size.

The details page displays the sensor’s information, such as Serial number; manufacture ID, model number, hardware version and software version.

The model number of Speedometer sensor is 30.

Compass

To use the compass for the first time, the compass reading is not accurate; please calibrate the compass.

Step:

- On the main menu page, click Settings.
- Select “Sensor” to enter the sensor settings menu.
- Select “Compass”. Press the button to calibrate the compass.

Altimeter

Users can use GPS to calibrate or manually calibrate the altimeter.



Step:

- On the main menu page, click Settings.
- Select “Sensor” to enter the sensor settings menu.
- Select “Altimeter” to view the option of altimeter calibration mode. You can select “GPS” or “Manual” calibration.
- If "Adopt GPS Altimeter" is selected, a confirmation message will appear on the screen.
- If you choose manual calibration, enter the current altitude. The initial value that appears on the keypad can be used as reference for the current altitude data.

Screen

When you touch the screen, you can adjust the screen calibration if there is a difference on the response location.


2/6
Cadence Sensor
None
Speedometer
None
Calibrate screen?
Screen
Click to calibrate
Carefully press and briefly hold stylus on the center of the target. Repeat as the target moves around the screen.
New calibration settings have been measured. Tap the screen to register saved data. Wait for 30 seconds to cancel saved data and keep the current setting.
Time limit : 23 sec

Step:

- On the main menu page, click Settings.
- Select “Sensor” to enter the sensor settings menu.
- Select “Screen”, a confirmation message will appear on the screen. Press the confirmation button, and start to calibrate screen.
- After calibrating the screen, tap the screen or wait for 30 seconds to exit.

System

Left key- Info pages

Use the “Left key- Info pages” to set the project displayed on Trip information and the auto-flip.

Select pages

You can select 1 ~5 information page to set the shortcuts for the “Left key- Info pages”.

Step:

- On the main menu page, click Settings.
- Select “System”.
- Select” “Left key- Info pages”.
- Select” “Select pages”.
- You can select by checking items to be displayed for the Left Key operation. Available options are: Trip Computer1, Trip Computer2, Altitude Graph, Compass and Information.
- When completed, it returns to the main menu page.

Time to flip

Flip page time is the selected time interval to automatically switch among Info Page for the Left Key operation.



Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select” “Left key- Info pages” to enter the left menu options.
- From the list, select” “Time to flip” to automatic exchange the information page at a preset time. When completed, it returns to main menu page.

Note: When using the automatic switching mode, you need to select more than one information page.

Altitude mode

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Altitude mode” to enter the altitude mode options. Select your option, and when completed, it returns to main menu page.

Note: "Auto select": If GPS is already in the positioning mode or the barometer has not been calibrated, the device will automatically use GPS to measure the altitude. If both cases happened at the same time, the default is barometer.

Speed mode

FunTrek130 Pro/ FunTrek130 provides speed display including speedometer and GPS.

Step:

- On the main menu page, click "Settings" icon to enter the settings page. Select "System Settings".
- Select" "Speed mode" to enter the speed mode options. Select your option, and when completed, it returns to main menu page.

Note: "Auto select": If GPS is already in the positioning mode or the speedometer has not been calibrated, the device will automatically use GPS to measure the speed. If both cases happened at the same time, the default is speedometer.

Screen Lock

Step:

- On the main menu page, click "Settings" icon to enter the settings page. Select "System Settings".
- Select "Screen lock" to enter the screen lock mode options. Select your option, and when completed, it returns to main menu page.

Backlight

Step:

- On the main menu page, click "Settings" icon to enter the settings page. Select "System Settings".
- Select "Backlight" to enter the backlight mode options.
- Select your option, and when completed, it returns to the main menu page.

Beep

Step:

- On the main menu page, click "Settings" icon to enter the settings page. Select "System Settings".
- Select "Beep" to enter the beep submenu. You can change settings for "sound" and "volume".
- Select "Sound" to set the sound setting.

- Select “Volume” to set the volume setting.

Note: For details on beep information, refer to the device pop-up message.

Auto shutdown

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Auto Power Off” to set the auto power off setting.

Note:

✧ *If FunTrek130 fails to acquire a fix within the set time, it will automatically power off.*

✧ *If a satellite fix is acquired within the set time, the timer will be reset.*

Coordinates Setup

Coordinates Format

User can choose the appropriate format for their use.

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Set Coordinate” to view the coordinate lists.
- Select “Coordinate Format” to set the coordinate format.
- When completed, it returns to the previous screen.

User Grid:



- Select User Grid in Coordinates Format List, and enter the parameter page.
- Select the parameter you want to define, and the digital keyboard appears. In longitude and latitude page, you can use E/W and S/N to change the directions.
- Set the respective parameters. When completed, it returns to the previous screen.

Coordinate Datum

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Set Coordinate” to view the coordinate lists.
- Select “Coordinate Datum” to set the coordinates.
- If you select “Beijing1954” or “Xian80” datum, you have to input the parameter. “a” and “1/f” cannot be edited.
- When completed, it returns to the previous screen.

Customizing the Coordinate Datum:

- On the “Datum” page, select “User Datum”.
- Set the respective parameters. When completed, it returns to the previous screen.

Units

Users can set the units of Speed/ Distance.

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Units” to enter the options list.
- Select “Metric” or “Imperial” units.
- When completed, it returns to the previous screen.

Time

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Time”.
- Select “Time Format”. Select from the following format: “24 hours” and “12 hours”.
- Select “Time Zone” to set the time zone.
- Select “Daylight saving time” to set enable or disable.

- When completed, it returns to the previous screen.

Storage media

Users can save track log files into the internal memory or the micro SD card.



Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Storage media”.
- Select “Holux Internal Memory” or “SD card”.
- When completed, a “Change will not take effect until the device restarts. Restart it right now?” message appears on the screen.
- User can restart the device to complete the setting.

Language

In the Language setup menu you can change the language interface. Available options are: Simplified Chinese, Traditional Chinese and English.

Step:

- On the main menu page, click “Settings” icon to enter the settings page.
- Select “System Settings” to enter menu options.
- Select “Language” to enter the language setup menu.
- Set your desired language. When completed, it returns to the previous menu.

Clear counters

Clear counters enable users to clear the existing trip information that contains with the Odometer, total CO_2/Tree Saved, and total rising/drop height information.

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Clear counters”, and select the items that you want to reset.
- When the “Reset confirmation” message appears on the screen, press the confirmation button to clear the selected items.

MSAS/WAAS/EGNOS

Enable the function to improve the GPS positioning accuracy.

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “MSAS/WAAS/EGNO”. Click “Open” to enable the MSAS/WAAS/EGNO function.

Holding right key

FunTrek130 Pro/ FunTrek130 offers the function that user can switch to WinCE.

Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Holding right key”.
- Select “Power off” to power off the device by pressing the right key; “Switch to WinCE” to switch to WinCE system.

！Note:

Generally, user is not recommended to enter the WINCE system of FunTrek130 Pro/ FunTrek130. In the WINCE, improper operation will cause the system malfunction.

Show tips at start



Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Show tips at start”.
- Select “Open” to show tips when you restart the device. If you select “Close”, the tips will not appear when you restart the device.
- When you restart the device, you can also disable the tips pop-up by checking the “Do not display tips on next start up”.

Alerts



Step:

- On the main menu page, click “Settings” icon to enter the settings page. Select “System Settings”.
- Select “Alert” to enter the alert lists.
- Select “Distance”, “BAR Altitude”, “Speed” or “Time” button to set the alert.
- Select “On (Click to input)” to enter the Digital Keypad, and then enter the appropriate value.

Note:

✧ *Before use altimeter function, please read the section of Product Caution/ About the*

altimeter.

- ✧ *When current altitude reaches the set value, the altitude alert message will appear ob the screen. The alert can help climbers to prevent the acute mountain sickness (AMS).*
- ✧ *If the altimeter detected current altitude reaches or exceeds the set value within 1 minute, the altitude alert message will appear on the screen.*
- ✧ *If "Repeat Alert" is selected then the alert will continue to appear on the screen when the current altitude is equal or exceeds the set value. To turn off alert, select "Alert Off".*
- ✧ *A warning message will appear on the screen when the current speed has reached its default value.*
- ✧ *When the current speed reaches the set value, the speed alert message will appear on the screen.*

Profiles

Step:



- On the main menu page, click “Settings” icon to enter the settings page.
- Click “Profiles” icon to select “Current settings” or “Factory defaults”.
- Click “Factory defaults” to restore the factory default settings.

Notes: the device can storage 10 settings.

About

FunTrek 130 Pro
Handheld OS V2.25.EN
Handheld AP V2.01.003
Microsoft® Windows® CE 5.0
Copyright© 2004 Microsoft Corporation.
All other trademarks are the property of their respective owners. The program is protected by China and international copyright law.

This product includes EXpat XML parser code.
THE FOLLOWING COPYRIGHT NOTICE AND PERMISSSIONS NOTICE APPLY SOLELY TO THE EXPAT XML PARSER CODE.
http://expat.sourceforge.net/
Copyright ©1998, 1999, 2000 Thai Open Source Software Centre Ltd. and Clark Cooper.
Copyright © 2001, 2002, 2003 Expat maintainers.

You can get the software version information of the operation system (OS) and applications for this device.

ezTour Plus Installation

To download the recorded track log and view it on your computer, first, you will need to install the bundled **ezTour Plus**. Insert the bundled installation CD into the computer's CD drive to install ezTour Plus. For details, please refer to the included **ezTour Plus** user manual.

End of Holux FunTrek130 Pro/ FunTrek130's user manual

Wish you a pleasant use

HOLUX

Website: www.holux.com